WARNING WET/DRY VACUUM

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, <u>DO NOT USE THIS EQUIPMENT!!!</u>

IMPORTANT SAFETY RULES TO FOLLOW

- 1. **FOR DRY UNITS:** Do not use without paper filter bag and main filter in place.
- 2. **FOR WET UNITS:** Remove filter bag before using. Electric shock could occur if nozzle is used on wet surfaces.
- 3. Unplug from outlet when not in use.
- 4. To avoid electric shock, do not expose to rain.
- 5. Do not use with damaged cord or plug. Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum over cord. Keep cord away from heated surfaces.
- 6. Do not unplug by pulling on cord. Do not handle plug with wet hands.
- 7. Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- 8. Do not use to pick-up flammable or combustible liquids such as gasoline or use in areas where they may be present. Fire or explosion may occur. And never use in a hazardous environment!

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. **IF** there is any doubt as to the operation or safety of the equipment,

DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!
FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH