WARNING BBQ GRILL

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, <u>DO NOT USE THIS EQUIPMENT!!!</u>

WARNING: Barbecuing creates harmful chemicals such as carbon monoxide and acrylamide which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to <u>www.P65warnings.ca.gov</u>

WARNINGS:

All parts of this BBQ get extremely HOT. Use extreme caution whenever adding or adjusting fuel, food or adjusting grill. Always let the BBQ cool completely before moving or transporting.

Keep all children, bystanders & pets at a safe distance.

Provide adequate ventilation whenever using this BBQ. Fuel combustion consumes oxygen & gives off deadly carbon monoxide gas. Never operate indoors!

Use extreme care when placing BBQ; keep it a safe distance from combustibles, like tall grasses & over hanging structures. Always keep a garden hose, or fire extinguisher nearby.

Put BBQ out completely before returning. Never transport or move with hot or burning coals.

SET-UP INSTRUCTIONS:

- 1. Place grill on a level area clear of combustible items & remove the grill top.
- 2. Line the firebox with heavy duty aluminum foil to improve heat reflection and for easier clean-up.
- 3. Start with 30-40 lbs. of charcoal.
- 4. Place charcoal in 2 or 3 even piles in the firebox & ignite according to manufacturer's recommendations. Follow all caution & safety measures set forth in this manual & on the charcoal manufacture's packaging.
- 5. Before placing grill top over hot coals, coat generously with vegetable oil or cooking spray to prevent food from sticking.

OPERATING INSTRUCTIONS:

- 1. Place grill on a level area clear of combustible items & remove the grill top.
- 2. Line the firebox with heavy duty aluminum foil to improve heat reflection and for easy clean-up.
- 3. Start with 30-40 lbs. of charcoal.
- 4. Place charcoal in 2 or 3 even piles in the firebox & ignite according to manufacturer's recommendations. Follow all caution & safety measures set forth in this manual & on the charcoal manufacture's packaging.
- 5. When coals are ready, evenly distribute them throughout the firebox creating a thickness of 1-2 briquettes for ideal coking.
- 6. The grill top is designed for direct cooking only so place food directly on grill top. Placing pots, pans, or other cooking accessories on grill can be dangerous & is not recommended.
- 7. <u>Before placing grill top over hot coals</u>, coat generously with vegetable oil or cooking spray to prevent food from sticking.
- 8. Select the desired cooking height & slide the grill top onto the firebox.
- 9. Add 10-15 lbs. of charcoal each hour while the grill is in use to maintain temperature.
- 10.Keep a spray bottle filled with water close by to help reduce flair-ups while cooking simply spray the coals directly to extinguish & cool the area.
- 11.Immediately after cooking, remove grill grate & set aside to cool. This will aid in the cleanup & prevent grease from baking onto the grill top.
- 12. After the coals are cold, crumple the aluminum foil with ash inside & dispose of in an approved manner.

CLEANING & CARE

- 1. Immediately after cooking, remove grill grate & set aside to cool. This will aid in the cleanup & prevent grease from baking onto the grill top.
- 2. After the coals are cold, crumple the aluminum foil with ash inside & dispose of in an approved manner. **WARNING:** Never pour water over hot coals to extinguish them as this can warp the firebox.
- 3. When the grill top has cooled, clean using a commercial degreaser & a pressure washer if necessary. Remove excessive carbon build-up with a non-metallic scouring pad, like a Scotch-Brite pad. <u>NEVER</u> use a wire brush.
- 4. Clean firebox with a solution of hot soapy water & dry completely before returning. Never transport or move with hot or burning coals.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, <u>DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!</u>FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH