WARNING POST PULLER

Any piece of equipment can be dangerous if not operated properly. <u>YOU</u> are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

WARNING: This product can expose you to chemicals including Chromium from steel products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

DANGER: This equipment has multiple pinch points that can cause dismemberment or death. Keep hands, feet and all other body parts clear at all times.

BIG RED POST PULLER

www.bigredpostpuller.com 1-866-866-6284 PATENT 6527250 B1

LOAD CARRYING CAPACITY 400 POUNDS

INSTRUCTIONS:

- 1. Put post puller up against post. Make sure base is on level ground (block up if necessary). Lift the reversing latch to its upright position.
- 2. Check to ensure there are no obstacles for a clean lift. Wrap chain around post 2 or more times & let slide down until tight, pulling straight up.
- 3. Start jacking until post is loose while holding the top handle to guide straight up. Then tilt back & roll
- 4. Unload. Start over with next post.

WARNING: THE JACK MUST BE LOADED WITH A MINIMUM OF 110LBS TO LOWER STEP BY STEP, OTHERWISE THE LIFTING NOSE WILL DROP. JACKING UP AT AN ANGLE CAN BEND THE I-BEAM.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. If there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!**

FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH